



Master Rigid E


600x600, 1200x600, 1200x1200

M317




1. Ecophon Master Rigid E


2. Connect T24 Main runner



3. Connect T24 Cross tee,
L=1200



4. Connect T24 Cross tee,
L=600




5. Connect Adjustable hanger




6. Connect Hanger clip



7. Connect Hold down clip E



8. Connect Channel trim




9. Connect Direct fixing bracket



10. Ecophon Extra Bass 1200x600x50



Demounting
600x600 → 30
1200x600 → 31
1200x1200 → 32




Ecophon[®]
SAINT-GOBAIN



A SOUND EFFECT ON PEOPLE



www.ecophon.com







600x600 → 3
1200x600 → 3
1200x1200 → 19























600x600 → 10
1200x600 → 15



600x600










14












1200x600







15







16





































26



27





Demounting
 600x600 →0
 1200x600 →1
 1200x1200 →2

